Operation Instruction

M226

Unshielded Cat6 Keystone Coupler

1



Insert the keystone coupler into the wall plate with the clip up.

2



Put the bottom of the coupler into the port first.

3



Use the bottom as a level and insert the coupler.

4



Successful if you hear the sound.