Operation Instruction

KJ23-C7

Cat7 Toolless Plug

1



Insert the strain relief boot.

2



Strip off the cable jacket.

3



Strip off the foiled shielding on each twisted pair.

4



Wrap the aluminum foil around the cable jacket.

5



Arrange eight wires and wrap the copper foil.

6



Insert eight wires into the conductor holder according to T568A or T568B wiring diagrams.

7



Cut off the excess wires.

8



Check the wiring diagram.

9



Align the conductor holder with the slots of the wire cap.

10



Cover the wire cap and press it.

11



Tighten the strain relief boot.

12



Successful termination.