Operation Instruction

KJ18

RJ45 Cat8 Toolless Plug

1



Thread boot and tightening sleeve into the ethernet cable.

2



Use a wire stripper to peel off the jacket.

3



Separate the wires. Note that it does not apply to stranded wire.

4



Thread the core wire into the cable arrangement according to the T568B sequence, and cut off the excess core.

5



As shown, the second row is shorter.

6



As shown.

7



Click the feed-through cap into the CAT8 connector, press the close the cover.

8



Tighten the boot.

9



Finish.