Operation Instruction

SJ650BK

Shielded Two-piece Cat7 Connector

1

Slide the boot on the cable.

2

Strip the cable jacket.

3

Straighten the wires.

4

Arrange the wires.

5

Cut the wires in oblique angle.

6

Put the wires into the load bar in turn.

7

Cut excess wires.

8

Ensure eight wires are placed in the right position.

9

Insert the plug into the cavity and crimp it.

10

Press the ground collar.

11

Crimp the ground collar.

12

Slide the boot onto the plug.