Operation Instruction

M235

Short-body Cat6 Waterproof Coupler

1



Slide the coupler cap onto the cable.

2



Place the rubber grommet onto the patch cable.

3



Slide the coupler housing on the cable.

4



Squeeze the rubber grommet into the coupler housing.

5



Insert the RJ45 plug into the coupler port.

6



Tighten the waterproof coupler.

7



Screw the coupler housing to the cap.

8



Repeat the same steps for the other side. Complete!